

**SPILL PRIORITY LIST - September 1 through no later than March 31.**

The Spill Priority List defines the project priority order for lack-of-load spill in order to manage TDG on a system-wide basis.

Level	Priority	Project	Example Spill Cap (kcfs)
<b>LEVEL 1</b> <b>State TDG Standard <sup>1</sup></b>  <b>≤ 110%</b>	1	BON	70
	2	LWG	20
	3	LGS	18
	4	LMN	18
	5	IHR	25
	6	MCN	48
	7	JDA	20
	8	TDA	45
	9	DWR	35% of total flow
	10	CHJ	25
	11	GCL	0 (OT) or 5 (DG) <sup>2</sup>
<b>LEVEL 2</b>  <b>≤ 115%</b>	12	BON	100
	13	LWG	30
	14	LGS	23
	15	LMN	23
	16	IHR	35
	17	MCN	80
	18	JDA	80
	19	TDA	60
	20	CHJ	61
	21	GCL	5 (OT) or 10 (DG) <sup>2</sup>
<b>LEVEL 3</b>  <b>≤ 120%</b>	22	BON	140
	23	LWG	45
	24	LGS	52
	25	LMN	44
	26	IHR	75
	27	MCN	140
	28	JDA	144
	29	TDA	135
	30	CHJ	150
	31	GCL	10 (OT) or 15 (DG)
<b>LEVELS 4-7 (125%, 127%, 130%, 135% TDG): same project Priority Order as Levels 2 and 3.</b>			

<sup>1</sup> Sep 1-Mar 31: State TDG standard for all projects is 110%.

<sup>2</sup> GCL spill is either via outlet tubes (OT) or drum gates (DG), depending on reservoir elevation (transition to DG at elevation 1267-1270 ft). OT spill produces more TDG.